

Installation Instructions

1. COM Data Loggers

Note: All COM data logger need to install relative driver for the logger to work:

- a) For RC-5, RC-61, GSP-6 models, please open “Driver for RC-5/RC-61; GSP-6” folder and install the “CH34x_Install_V1.5.pkg” driver.
- b) For RC-4/HA/HC models, please open “Driver for RC-4/4HA/4HC” folder and install the “Silicon Labs VCP Driver Installer.mpkg” driver.

2. USB Data Loggers

Note: All USB data logger only need to drag the “ElitechLog.app” icon into the “Applications” folder.

- a) Models includes: RC-18/19, RC-5+, RC-51/51H, LogEt 1/TH/Bio, LogEt 6, LogEt 8 T/TE/PTE/TH, LogEt 8 Food/Life Science, TemLog ST5, TemLog20/20H, Tlog100 Series.
- b) Open ElitechLog software after the Connect the data logger with your computer, open the ElitechLog software and wait for the data downloading complete before usages.

3. ElitechLog software support macOS system with version 10.10 and above.

Or otherwise, please update it first and repeat above operation for installation.